


# CHIMNEY PATCH & REPAIR

CPR (Chimney Patch & Repair) is a fast setting, high early strength, acid resistant, hand mixed and hand applied product for filling voids and repairing concrete, brick or other masonry constructed manholes or catch basins.

CPR is fiber reinforced and it is sure to resuscitate a structure back into good health.

<b>BOND</b>	140 PSI
<b>SHRINKAGE</b>	0% at 90% relative humidity
<b>MIX RATIO</b>	1 part water – 3 parts CPR
<b>PLACEMENT TIME</b>	5-10 minutes
<b>FLOW RELEASE</b>	15-30 minutes after replacement
<b>PACKAGING</b>	5 gallon pail (46 lbs)
<b>YIELD</b>	1/2 cu. Ft. per pail

**CAUTION**

All persons working with CPR should wear dust mask, eye protection and gloves

# CHIMNEY PATCH & REPAIR (CPR)

## APPLICATION

- Wash surface clean
- Remove loose brick, mortar and debris
- Mix in small quantities, only the amount that can applied within 10 minutes
- Mix with water to a dough-like consistency
- When filling voids, hold in place with hand or trowel until material will remain in place
- Allow CPR to set for a minimum of 4 hours before applying Flex-Seal
- When repairing inverts, trowel to contour of invert and onto bench a minimum of 1/2" thick



## COMPRESSIVE STRENGTH

15 Minutes	200 PSI
1 Hour	800 PSI
6 Hours	1400 PSI
24 Hours	2000 PSI
28 Days	4500 PSI



INDEPENDENT SEWER  
CONSULTING SERVICES PTY LTD

Unit 13 /1 Adept Lane Bankstown NSW 2200

Ph 02 9790 2024 | [sales@iscservices.com.au](mailto:sales@iscservices.com.au)

[www.iscservices.com.au](http://www.iscservices.com.au)